

# FORKLIFT GUIDE

## I. UNPACKING AND MACHINE IDENTIFICATIONS

All Techno machines are shipped assembled and secured to a wooden pallet.

### 1.1

Unpack all items that shipped with your machine. Check the items against the packing slip to be sure nothing was left out. Notify Techno immediately if you are missing any pieces of your shipment.

A toolbox and other accessories such as vacuum hosing and leveling feet may be packed under the machine during shipping.


Fig. 1.1

● Please note the 4 Forklift Tubes on the front and rear of the machine.

● If required, there are 4 Forklift Tubes on the sides of the machine.



Rear of Machine



Front of Machine

## II. MEASURING FORKS AND FORKLIFTING MACHINE

### 2.1

Forks must be centered in the front of the machine (shown in Fig 2.1).





Fig. 2.1

### 2.2



Measure the distance between the forks. (shown in Fig 2.2).

Fig. 2.2

## SAFETY WARNING: DO NOT LIFT OR MOVE MACHINE USING GANTRY



**For safety and to prevent damage to the machine and cables, Lift Machine Using Forklift Tubes ONLY**

Depending on machine size — SEE QUOTE FOR MACHINE WEIGHT

NOTE: Forklift capacity must be adequate to safely lift the machine.

It is recommended to have Fork Lift Extensions to better support the load.

### 2.3

Take care not to damage the valves on the front of the machine. Slowly move in close to the machine.



Fig. 2.3

### 2.4




Fig. 2.4

Forklift your machine up from the floor and remove the wooden pallet.